

# Garden Stepping Stones



## **Materials in kit:**

*Quickcrete© Sand Mix*

*Mold (Aluminum Cake Pan)*

*Plastic Spoon*

*Paper towels*

*Assorted Materials to Decorate  
the Surface*

## **You will need to provide:**

*Water*

Begin by choosing a design for the stepping stone.  
Lay out your design in the materials you wish to use.

After you have your design ready, you will mix the concrete. Cut a corner of the bag and CAREFULLY and GENTLY pour the dry mix in the mold. Be careful not to inhale the dust.

Add a little water at a time. Stir together until all the mix is moistened. Continue to add small amounts of water until the mix is like thick mud. Be careful not to add too much water.

Spread the cement around the mold and smooth the surface. Now you can begin embedding your design in the cement. Gently push each marble (or other material) into the cement. You might give it a little wiggle to get it set firmly.

If you get a hazy film of liquid on the surface of your marbles while you are setting them, do not try to wipe it off while the concrete is wet. This will just spread the water further. Wait until the stepping stone is dry and use a rag to wipe off the dried film.

When the cement dries the materials will be embedded in the stone and should not fall out. Allow 48 to 72 hours for the cement to dry and cure before removing the stone from the mold.